

Meritor® AllFit SimpleCheck™ Installation.

The Meritor SimpleCheck can be installed on standard or long-stroke air brake chambers with welded or threaded clevises. When installing SimpleCheck on a brake chamber pushrod, make certain there is enough clearance between the clevis lock nut and the brake chamber housing.

Instructions:

1. Chock the tires to make certain the vehicle will not move. Release the parking brakes.
2. Apply the service brake several times to make certain that all pushrods are at a fully released position.
3. Install the SimpleCheck green disc directly onto the pushrod at the back face of the air brake chamber housing. Mounted directly onto the pushrod in that way, the green SimpleCheck disc simply moves with the pushrod when the brake is applied, providing a visual indication of whether the pushrod stroke is acceptable.
4. Installation is complete.



MERITOR®

Meritor Heavy Vehicle Systems, LLC
7975 Dixie Highway
Florence, Kentucky 41042 USA

U.S. 888-725-9355
Canada 800-387-3889

©2016 Meritor, Inc.
Litho in USA Issued 1-16
MISC-1632